



EL10	EL10a	EL10b	EL11	XD21	XD28	XZ1a,b	XZ2a,b	XZ3a-c	R	HIS1	XZ1c,d	XZ2c,d	XZ3d-f	R	HIS
WL61	WL62	WL63	WL64	WL65	WL66	WL67	WL68	WL69	WL70	WL71	WL72	WL73	WL74		WL75
J 3x1,5 RE	J 3x1,5 RE	J 3x1,5 RE	J 3x1,5 RE	J3x2,5RE	J3x2,5RE	J3x2,5RE	J3x2,5RE	J3x2,5RE		J5x1,5RE	J3x2,5RE	J3x2,5RE	J3x2,5RE		J5x1,5RE
typ III	typ III	typ III	typ III	typ III	typ III	typ III	typ III	typ III		typ III	typ III	typ III	typ III		typ III